

### Revision History 256Mb AS4C16M16D1-5BAN 96 ball FBGA PACKAGE

Revision	Details	Date
Rev 1.0	Initial Release	Aug.2020

ALLIANCE MEMORY Inc. reserves the right to change products or specification without notice. 12815 NE 124th Street Suite D, Kirkland, WA 98034 USA, Main +1(425)868-4456 Fax:+1 (425)898-8628

Confidential - 1 of 64 - Rev.1.0 Aug. 2020



### 16M x 16 bit DDR Synchronous DRAM (SDRAM)

Initial Release (Rev. 1.0, Aug. /2020)

#### **Features**

- Fast clock rate: 200MHz
- AEC-Q100 Compliant
- Differential Clock CK & CK
- Bi-directional DQS
- DLL enable/disable by EMRS
- Fully synchronous operation
- Internal pipeline architecture
- Four internal banks, 4M x 16-bit for each bank
- Programmable Mode and Extended Mode registers
  - CAS Latency: 2, 2.5, 3
  - Burst length: 2, 4, 8
  - Burst Type: Sequential & Interleaved
- Individual byte write mask control
- DM Write Latency = 0
- Auto Refresh and Self Refresh
  - Not support self refresh function with T<sub>A</sub> > 85°C
- 8192 refresh cycles / 16ms
- Precharge & active power down
- Operating temperature: T<sub>A</sub> = -40~105°C (Automotive)
- Power supplies: VDD & VDDQ =  $2.5V \pm 0.2V$
- Interface: SSTL 2 I/O Interface
- Package: Pb free and Halogen free
- 60 Ball, 8x13x1.2 mm (max) FBGA

#### Overview

The AS4C16M16D1 SDRAM is a high-speed CMOS double data rate synchronous DRAM containing 256 Mbits. It is internally configured as a quad 4M x 16 DRAM with a synchronous interface (all signals are registered on the positive edge of the clock signal, CK). Data outputs occur at both rising edges of CK and  $\overline{\text{CK}}$ .

Read and write accesses to the SDRAM are burst oriented: accesses start at a selected location and continue for a programmed number of locations in a programmed sequence. Accesses begin with the registration of a BankActivate command which is then followed by a Read or Write command. The AS4C16M16D1 provides programmable Read or Write burst lengths of 2, 4, or 8. An auto precharge function may be enabled to provide a self-timed row precharge that is initiated at the end of the burst sequence. The refresh functions, either Auto or Self Refresh are easy to use. In addition, AS4C16M16D1 features programmable DLL option. By having a programmable mode register and extended mode register, the system can choose the most suitable modes to maximize its performance. These devices are well suited for applications requiring high memory bandwidth; result in a device particularly well suited to high performance main memory and graphics applications.

#### **Table 1A. Ordering Information**

Product part No	Org	Temperature	Max Clock (MHz)	Package
AS4C16M16D1-5BAN	16M x 16	Automotive -40°C to 105°C	200	60-ball FBGA

#### **Table 1B. Speed Grade Information**

Speed Grade	Clock Frequency	CAS Latency	tRCD(ns)	tRP(ns)
DDR1-400	200MHz	3	15	15

Confidential - 2 of 64 - Rev.1.0 Aug. 2020




Figure 1. Ball Assignment (Top View)

	1	2	3	•••	7	8	9
Α	VSSQ	DQ15	vss		VDD	DQ0	VDDQ
В	DQ14	VDDQ	DQ13		DQ2	VSSQ	DQ1
С	DQ12	VSSQ	DQ11		DQ4	VDDQ	DQ3
D	DQ10	VDDQ	DQ9		DQ6	VSSQ	DQ5
Е	DQ8	VSSQ	UDQS		LDQS	VDDQ	DQ7
F	VREF	VSS	UDM		LDM	VDD	NC
G	,	СК	©K CK		WE	CAS	
Н	,	(A12)	CKE		RAS	CS	
J	,	(A11)	(A9)		BA1	BAO	
K		(A8)	A7		A0	(A10)	
L		(A6)	<b>A</b> 5		A2	(A1)	
М		(A4)	vss		VDD	(A3)	

Confidential - 3 of 64 - Rev.1.0 Aug. 2020

Figure 2. Block Diagram





### **Pin Descriptions**

Table 2. Pin Details

Symbol	Туре	Description
CK, CK	Input	<b>Differential Clock:</b> CK, $\overline{\text{CK}}$ are driven by the system clock. All SDRAM input signals are sampled on the positive edge of CK. Both CK and $\overline{\text{CK}}$ increment the internal burst counter and controls the output registers.
CKE	Input	Clock Enable: CKE activates (HIGH) and deactivates (LOW) the CK signal. If CKE goes low synchronously with clock, the internal clock is suspended from the next clock cycle and the state of output and burst address is frozen as long as the CKE remains low. When all banks are in the idle state, deactivating the clock controls the entry to the Power Down and Self Refresh modes.
BA0, BA1	Input	<b>Bank Activate:</b> BA0 and BA1 define to which bank the BankActivate, Read, Write, or BankPrecharge command is being applied.
A0-A12	Input	Address Inputs: A0-A12 are sampled during the BankActivate command (row address A0-A12) and Read/Write command (column address A0-A8 with A10 defining Auto Precharge).
CS	Input	Chip Select: $\overline{CS}$ enables (sampled LOW) and disables (sampled HIGH) the command decoder. All commands are masked when $\overline{CS}$ is sampled HIGH. $\overline{CS}$ provides for external bank selection on systems with multiple banks. It is considered part of the command code.
RAS	Input	<b>Row Address Strobe</b> : The $\overline{RAS}$ signal defines the operation commands in conjunction with the $\overline{CAS}$ and $\overline{WE}$ signals and is latched at the positive edges of CK. When $\overline{RAS}$ and $\overline{CS}$ are asserted "LOW" and $\overline{CAS}$ is asserted "HIGH" either the Bank Activate command or the Precharge command is selected by the $\overline{WE}$ signal. When the $\overline{WE}$ is asserted "HIGH" the BankActivate command is selected and the bank designated by BA is turned on to the active state. When the $\overline{WE}$ is asserted "LOW" the Precharge command is selected and the bank designated by BA is switched to the idle state after the precharge operation.
CAS	Input	<b>Column Address Strobe:</b> The $\overline{\text{CAS}}$ signal defines the operation commands in conjunction with the $\overline{\text{RAS}}$ and $\overline{\text{WE}}$ signals and is latched at the positive edges of CK. When $\overline{\text{RAS}}$ is held "HIGH" and $\overline{\text{CS}}$ is asserted "LOW" the column access is started by asserting $\overline{\text{CAS}}$ "LOW". Then, the Read or Write command is selected by asserting $\overline{\text{WE}}$ "HIGH" or "LOW".
WE	Input	Write Enable: The $\overline{\rm WE}$ signal defines the operation commands in conjunction with the $\overline{\rm RAS}$ and $\overline{\rm CAS}$ signals and is latched at the positive edges of CK. The $\overline{\rm WE}$ input is used to select the BankActivate or Precharge command and Read or Write command.
LDQS,	Input /	Bidirectional Data Strobe: Specifies timing for Input and Output data. Read Data
UDQS	Output	Strobe is edge triggered. Write Data Strobe provides a setup and hold time for data and DQM. LDQS is for DQ0~7, UDQS is for DQ8~15.
LDM,	Input	Data Input Mask: Input data is masked when DM is sampled HIGH during a write
UDM		cycle. LDM masks DQ0-DQ7, UDM masks DQ8-DQ15.
DQ0 - DQ15	Input / Output	Data I/O: The DQ0-DQ15 input and output data are synchronized with positive and negative edges of LDQS and UDQS. The I/Os are byte-maskable during Writes.
V <sub>DD</sub>	Supply	<b>Power Supply:</b> 2.5V ± 0.2V .
Vss	Supply	Ground

Confidential - 5 of 64 - Rev.1.0 Aug. 2020



V <sub>DDQ</sub>	Supply	<b>DQ Power:</b> 2.5V ± 0.2V. Provide isolated power to DQs for improved noise immunity.
Vssq	Supply	DQ Ground: Provide isolated ground to DQs for improved noise immunity.
VREF	Supply	Reference Voltage for Inputs: +0.5 x VDDQ.
NC	-	No Connect: These pins should be left unconnected.

Confidential - 6 of 64 - Rev.1.0 Aug. 2020



### **Operation Mode**

Fully synchronous operations are performed to latch the commands at the positive edges of CK. Table 3 shows the truth table for the operation commands.

Table 3. Truth Table (Note (1), (2))

Command	State	CKE <sub>n-1</sub>	CKEn	DM	BA0,1	<b>A</b> 10	A0-9, 11-12	CS	RAS	CAS	WE
BankActivate	Idle <sup>(3)</sup>	Н	Х	Х	V	Rov	w address	L	L	Н	Н
BankPrecharge	Any	Н	Х	Х	V	L	X	L	L	Н	L
PrechargeAll	Any	Н	Χ	Χ	Х	Ι	X	L	L	Н	L
Write	Active <sup>(3)</sup>	Н	Χ	Χ	V	L	Column	L	Н	L	L
Write and AutoPrecharge	Active(3)	Н	Х	Χ	<b>V</b>	Н	address (A0 ~ A8)	L	Н	L	L
Read	Active <sup>(3)</sup>	Н	Х	Х	V	L	Column	L	Н	L	Н
Read and Autoprecharge	Active(3)	Н	Х	Х	V	Н	address (A0 ~ A8)	L	Н	L	Н
(Extended) Mode Register Set	Idle	Н	Х	Х		OP (	code	L	L	L	L
No-Operation	Any	Н	Х	Х	Х	Х	Х	L	Н	Н	Н
Burst Stop	Active <sup>(4)</sup>	Н	Х	Х	Х	Х	X	L	Н	Н	L
Device Deselect	Any	Н	Х	Х	Х	Х	X	Н	Х	Χ	Χ
AutoRefresh	Idle	Н	Н	Х	Χ	Χ	X	L	L	L	Н
SelfRefresh Entry	Idle	Н	L	Χ	Χ	Χ	X	L	L	L	Н
SelfRefresh Exit	Idle	L	Н	Х	Χ	Х	X	Н	Χ	Χ	Χ
	(SelfRefresh)							L	Н	Н	Н
Precharge Power Down	Idle	Н	L	Χ	Х	Χ	X	Н	Х	Х	Х
Mode Entry								L	Н	Н	Н
Precharge Power Down	Any	L	Н	Х	Х	Χ	X	Н	Х	Χ	Χ
Mode Exit	(PowerDown)							L	Н	Н	Н
Active Power Down Mode	Active	Н	L	Х	Х	Х	X	Н	Х	Х	Χ
Entry								L	V	V	V
Active Power Down Mode	Any	L	Н	Х	Х	Χ	X	Н	Х	Х	Χ
Exit	(PowerDown)							L	Н	Н	Н
Data Input Mask Disable	Active	Н	Х	L	Χ	Χ	Х	Χ	Х	Χ	Χ
Data Input Mask Enable <sup>(5)</sup>	Active	Н	Х	Н	Χ	Χ	X	Χ	Х	Х	Х

#### Note:


- 1. V=Valid data, X=Don't Care, L=Low level, H=High level.
- 2. CKE<sub>n</sub> signal is input level when commands are provided. CKE<sub>n-1</sub> signal is input level one clock cycle before the commands are provided.
- 3. These are states of bank designated by BA signal.
- 4. Device state is 2, 4, and 8 burst operation.
- 5. LDM and UDM can be enabled respectively.

Confidential - 7 of 64 - Rev.1.0 Aug. 2020

#### Mode Register Set (MRS)

The Mode Register stores the data for controlling various operating modes of a DDR SDRAM. It programs CAS Latency, Burst Type, and Burst Length to make the DDR SDRAM useful for a variety of applications. The default value of the Mode Register is not defined; therefore the Mode Register must be written by the user. Values stored in the register will be retained until the register is reprogrammed. The Mode Register is written by asserting Low on  $\overline{\text{CS}}$ ,  $\overline{\text{RAS}}$ ,  $\overline{\text{CAS}}$ ,  $\overline{\text{WE}}$ , BA1 and BA0 (the device should have all banks idle with no bursts in progress prior to writing into the mode register, and CKE should be High). The state of address pins A0~A12 and BA0, BA1 in the same cycle in which  $\overline{\text{CS}}$ ,  $\overline{\text{RAS}}$ ,  $\overline{\text{CAS}}$  and  $\overline{\text{WE}}$  are asserted Low is written into the Mode Register. A minimum of two clock cycles, tMRD, are required to complete the write operation in the Mode Register. The Mode Register is divided into various fields depending on functionality. The Burst Length uses A0~A2, Burst Type uses A3, and CAS Latency (read latency from column address) uses A4~A6. A logic 0 should be programmed to all the undefined addresses to ensure future compatibility. Reserved states should not be used to avoid unknown device operation or incompatibility with future versions. Refer to the table for specific codes for various burst lengths, burst types and CAS latencies.

**Table 4. Mode Register Bitmap** 



Burst Length Field (A2~A0)

This field specifies the data length of column access using the A2~A0 pins and selects the Burst Length to be 2, 4, 8.

Table 5. Burst Length

A2	A1	A0	Burst Length
0	0	0	Reserved
0	0	1	2
0	1	0	4
0	1	1	8
1	0	0	Reserved
1	0	1	Reserved
1	1	0	Reserved
1	1	1	Reserved

Addressing Mode Select Field (A3)

The Addressing Mode can be one of two modes, either Interleave Mode or Sequential Mode. Both Sequential Mode and Interleave Mode support burst length of 2, 4 and 8.

Table 6. Addressing Mode

A3	Addressing Mode
0	Sequential
1	Interleave

Confidential - 8 of 64 - Rev.1.0 Aug. 2020



• Burst Definition, Addressing Sequence of Sequential and Interleave Mode

**Table 7. Burst Address ordering** 

Purat Langth	S	tart Addres	SS	Cognontial	Interlegue
Burst Length	A2	A1	A0	Sequential	Interleave
2	Х	X	0	0, 1	0, 1
2	X	X	1	1, 0	1, 0
	X	0	0	0, 1, 2, 3	0, 1, 2, 3
4	X	0	1	1, 2, 3, 0	1, 0, 3, 2
4	X	1	0	2, 3, 0, 1	2, 3, 0, 1
	X	1	1	3, 0, 1, 2	3, 2, 1, 0
	0	0	0	0, 1, 2, 3, 4, 5, 6, 7	0, 1, 2, 3, 4, 5, 6, 7
	0	0	1	1, 2, 3, 4, 5, 6, 7, 0	1, 0, 3, 2, 5, 4, 7, 6
	0	1	0	2, 3, 4, 5, 6, 7, 0, 1	2, 3, 0, 1, 6, 7, 4, 5
8	0	1	1	3, 4, 5, 6, 7, 0, 1, 2	3, 2, 1, 0, 7, 6, 5, 4
0	1	0	0	4, 5, 6, 7, 0, 1, 2, 3	4, 5, 6, 7, 0, 1, 2, 3
	1	0	1	5, 6, 7, 0, 1, 2, 3, 4	5, 4, 7, 6, 1, 0, 3, 2
	1	1	0	6, 7, 0, 1, 2, 3, 4, 5	6, 7, 4, 5, 2, 3, 0, 1
	1	1	1	7, 0, 1, 2, 3, 4, 5, 6	7, 6, 5, 4, 3, 2, 1, 0

#### CAS Latency Field (A6~A4)

This field specifies the number of clock cycles from the assertion of the Read command to the first read data. The minimum whole value of CAS Latency depends on the frequency of CK. The minimum whole value satisfying the following formula must be programmed into this field.  $t_{CAC}(min) \le CAS$  Latency X  $t_{CK}$ 

**Table 8. CAS Latency** 

A6	A5	A4	CAS Latency
0	0	0	Reserved
0	0	1	Reserved
0	1	0	2 clocks
0	1	1	3 clocks
1	0	0	Reserved
1	0	1	Reserved
1	1	0	2.5 clocks
1	1	1	Reserved

#### • Test Mode field (A8~A7)

These two bits are used to enter the test mode and must be programmed to "00" in normal operation.

Table 9. Test Mode

A8	A7	Test Mode
0	0	Normal mode
1	0	DLL Reset

#### • (BA0, BA1)

### Table 10. MRS/EMRS

BA1	BA0	A12 ~ A0	
RFU	0	MRS Cycle	
RFU	1	Extended Functions (EMRS)	


Confidential - 9 of 64 - Rev.1.0 Aug. 2020



### **Extended Mode Register Set (EMRS)**

The Extended Mode Register Set stores the data for enabling or disabling DLL and selecting output driver strength. The default value of the extended mode register is not defined, therefore must be written after power up for proper operation. The extended mode register is written by asserting low on  $\overline{CS}$ ,  $\overline{RAS}$ ,  $\overline{CAS}$ , and  $\overline{WE}$ . The state of A0 ~ A12, BA0 and BA1 is written in the mode register in the same cycle as  $\overline{CS}$ ,  $\overline{RAS}$ ,  $\overline{CAS}$ , and  $\overline{WE}$  going low. (The device should have all banks idle with no bursts in progress prior to writing into the mode register, and CKE should be high). A1 is used for setting driver strength to normal, or weak. Two clock cycles are required to complete the write operation in the extended mode register. The mode register contents can be changed using the same command and clock cycle requirements during operation as long as all banks are in the idle state. A0 is used for DLL enable or disable. "High" on BA0 is used for EMRS. Refer to the table for specific codes.

Table 11. Extended Mode Register Bitmap



Confidential - 10 of 64 - Rev.1.0 Aug. 2020

**Table 12. Absolute Maximum Rating** 

Symbol	Item	Values	Unit
V <sub>I/O</sub>	Voltage on I/O Pins Relative to Vss	-0.5 ~ V <sub>DDQ</sub> + 0.5	V
V <sub>DD</sub> , V <sub>DDQ</sub>	Voltage on VDD, VDDQ Supply Relative to Vss	-1 ~ 3.6	V
VIN	Voltage on Inputs Relative to Vss	-1 ~ 3.6	V
TA	Ambient Temperature	-40 ~ 105	°C
Tstg	Storage Temperature	-55 ~ 150	°C
PD	Power Dissipation	1	W
los	Short Circuit Output Current	50	mA

**Note:** Absolute maximum DC requirements contain stress ratings only. Functional operation at the absolute maximum limits is not implied or guaranteed. Extended exposure to maximum ratings may affect device reliability.

Table 13. Recommended D.C. Operating Conditions (VDD = 2.5V ±0.2V, TA = -40~105 °C)

Symbol	Parameter	Min.	Max.	Unit
VDD	Power Supply Voltage	2.3	2.7	V
V <sub>DDQ</sub>	Power Supply Voltage (for I/O Buffer)	2.3	2.7	V
V <sub>REF</sub>	Input Reference Voltage	0.49 x V <sub>DDQ</sub>	0.51 x V <sub>DDQ</sub>	٧
V <sub>IH</sub> (DC)	Input High Voltage (DC)	V <sub>REF</sub> + 0.15	V <sub>DDQ</sub> + 0.3	٧
V <sub>IL</sub> (DC)	Input Low Voltage (DC)	-0.3	VREF - 0.15	V
VTT	Termination Voltage	VREF - 0.04	VREF + 0.04	V
V <sub>IN</sub> (DC)	Input Voltage Level, CK and $\overline{\text{CK}}$ inputs	-0.3	VDDQ + 0.3	V
V <sub>ID</sub> (DC)	Input Different Voltage, CK and $\overline{\text{CK}}$ inputs	0.36	V <sub>DDQ</sub> + 0.6	V
lı	Input leakage current	-2	2	μΑ
loz	Output leakage current	-5	5	μΑ
Іон	Output High Current (V <sub>OH</sub> = 1.95V)	-16.2	-	mA
loL	Output Low Current (VoL = 0.35V)	16.2	-	mA

Note: All voltages are referenced to Vss.

Table 14. Capacitance (VDD = 2.5V, TA = 25 °C)

Symbol	Parameter	Min.	Max.	Delta	Unit
C <sub>IN1</sub>	Input Capacitance (CK, CK)	1.5	2.5	0.25	pF
C <sub>IN2</sub>	Input Capacitance (All other input-only pins)	1.5	2.5	0.5	рF
CI/O	DQ, DQS, DM Input/Output Capacitance	3.5	4.5	0.5	pF

Note: These parameters are guaranteed by design, periodically sampled and are not 100% tested

Confidential - 11 of 64 - Rev.1.0 Aug. 2020



Table 15. D.C. Characteristics ( $V_{DD}$  = 2.5V  $\pm$  0.2V,  $T_A$  = -40~105 °C)

Parameter & Test Condition		-5		Nata
Parameter & Test Condition	Symbol	Max.	Unit	Note
OPERATING CURRENT: One bank; Active-Precharge; tRC=tRC(min); tCK=tCK(min); DQ,DM and DQS inputs changing once per clock cycle; Address and control inputs changing once every two clock cycles.	IDD0	78	mA	
OPERATING CURRENT: One bank; Active-Read- Precharge; BL=4; tRC=tRC(min); tCK=tCK(min); lout=0mA; Address and control inputs changing once per clock cycle	IDD1	84	mA	
PRECHARGE POWER-DOWN STANDBY CURRENT: All banks idle; power-down mode; tck=tck(min); CKE=LOW	IDD2P	6	mA	
PRECHARGE FLOATING STANDBY CURRENT: CKE = HIGH; $\overline{CS}$ =HIGH(DESELECT); All banks idle; tck=tck(min); Address and control inputs changing once per clock cycle; VIN=VREF for DQ, DQS and DM	IDD2F	36	mA	
PRECHARGE QUIET STANDBY CURRENT: CKE = HIGH;  CS =HIGH(DESELECT); All banks idle; tcκ=tcκ(min);  Address and other control input stadle at HIGH or LOW;  VIN=VREF for DQ, DQS and DM	IDD2Q	24	mA	
ACTIVE POWER-DOWN STANDBY CURRENT: one bank active; power-down mode; CKE=LOW; tck=tck(min)	IDD3P	24	mA	
ACTIVE STANDBY CURRENT: CS =HIGH; CKE=HIGH; one bank active; trc=trc(max);tck=tck(min); Address and control inputs changing once per clock cycle; DQ,DQS,and DM inputs changing twice per clock cycle	IDD3N	66	mA	
OPERATING CURRENT BURST READ: BL=2; READS; Continuous burst; one bank active; Address and control inputs changing once per clock cycle; tcκ=tcκ(min); lout=0mA;50% of data changing on every transfer	IDD4R	120	mA	
OPERATING CURRENT BURST Write: BL=2; WRITES; Continuous Burst; one bank active; address and control inputs changing once per clock cycle; tcκ=tcκ(min); DQ,DQS,and DM changing twice per clock cycle; 50% of data changing on every transfer	IDD4W	120	mA	
AUTO REFRESH CURRENT: tRC=tRFC(min); tCK=tCK(min)	IDD5	120	mA	
SELF REFRESH CURRENT: Self Refresh Mode ; CKE≦ 0.2V; tcκ=tcκ(min)	IDD6	4	mA	1
BURST OPERATING CURRENT 4 bank operation: Four bank interleaving READs; BL=4;with Auto Precharge; tRC=tRC(min); tCK=tCK(min); Address and control inputs change only during Active, READ, or WRITE command	IDD7	168	mA	

Confidential - 12 of 64 - Rev.1.0 Aug. 2020



Table 16. Electrical Characteristics and Recommended A.C.Operating Condition

 $(V_{DD} = 2.5V \pm 0.2V, T_A = -40\sim105 \, ^{\circ}C)$ 

	Damarastan		-5			Nata
Symbol	Parameter		Min.	Max.	Unit	Note
	(	CL = 2	7.5	12	ns	
tcĸ	Clock cycle time	CL = 2.5	6	12	ns	
	<u> </u>	CL = 3	5	12	ns	
tсн	Clock high level width		0.45	0.55	tск	
tcL	Clock low level width		0.45	0.55	tск	
t <sub>HP</sub>	Clock half period		(tcl, tcH)min	-	ns	2
tнz	Data-out-high impedance time from C	K, <del>CK</del>	-	0.7	ns	3
tız	Data-out-low impedance time from Ch	K, CK	-0.7	0.7	ns	3
toqsck	DQS-out access time from CK, $\overline{\text{CK}}$		-0.6	0.6	ns	
tac	Output access time from CK, CK		-0.7	0.7	ns	
toqsq	DQS-DQ Skew		-	0.4	ns	
trpre	Read preamble		0.9	1.1	tск	
<b>t</b> RPST	Read postamble		0.4	0.6	tск	
togss	CK to valid DQS-in		0.72	1.25	tск	
twpres	DQS-in setup time		0	-	ns	4
twpre	DQS write preamble		0.25	-	tск	
twpst	DQS write postamble		0.4	0.6	tск	5
t <sub>DQSH</sub>	DQS in high level pulse width		0.35	-	tcĸ	
togsl	DQS in low level pulse width		0.35	-	tск	
tıs	Address and Control input setup tim	е	0.7	-	ns	6
tıн	Address and Control input hold time		0.7	-	ns	6
tos	DQ & DM setup time to DQS		0.4	-	ns	
tон	DQ & DM hold time to DQS		0.4	-	ns	
tqн	DQ/DQS output hold time from DQS	3	thp - t <sub>QHS</sub>	-	ns	
trc	Row cycle time		55	-	ns	
trfc	Refresh row cycle time		70	-	ns	
tras	Row active time		40	70k	ns	
trcd	Active to Read or Write delay		15	-	ns	
t <sub>RP</sub>	Row precharge time		15	-	ns	
<b>t</b> RRD	Row active to Row active delay		10	-	ns	
twr	Write recovery time		15	-	ns	
twr	Internal Write to Read Command Do	elay	2	-	tск	
<b>t</b> MRD	Mode register set cycle time		10	-	ns	
trefi	Average Periodic Refresh interval		-	1.95	μS	7
txsrd	Self refresh exit to read command del	ay	200	-	tcĸ	
txsnr	Self refresh exit to non-read command	d delay	75	-	ns	
tdal	Auto Precharge write recovery + precharge	ge time	twr + trp	-	ns	
tDIPW	DQ and DM input puls width		1.75	-	ns	
tipw	Control and Address input pulse wid	lth	2.2	-	ns	
t <sub>QHS</sub>	Data Hold Skew Factor		-	0.5	ns	
t <sub>DSS</sub>	DQS falling edge to CK setup time		0.2	-	tcĸ	
t <sub>DSH</sub>	DQS falling edge hold time from CK		0.2	-	tcĸ	
t <sub>RAP</sub>	Active to Autoprecharge Delay		trcd or trasmin	_	ns	

Confidential - 13 of 64 - Rev.1.0 Aug. 2020

Table 17. Recommended A.C. Operating Conditions (VDD = 2.5V ±0.2V, TA = -40~105 °C)

Symbol	Parameter	Min.	Max.	Unit
VIH (AC)	Input High Voltage (AC)	VREF + 0.31	-	V
VIL (AC)	Input Low Voltage (AC)	-	VREF - 0.31	٧
VID (AC)	Input Different Voltage, CK and CK inputs	0.7	VDDQ + 0.6	٧
V <sub>IX</sub> (AC)	Input Crossing Point Voltage, CK and $\overline{\text{CK}}$ inputs	0.5 x VDDQ - 0.2	0.5 x V <sub>DDQ</sub> + 0.2	V


#### Note:

- 1) Enables on-chip refresh and address counters.
- 2) Min(t<sub>CL</sub>, t<sub>CH</sub>) refers to the smaller of the actual clock low time and actual clock high time as provided to the device.
- 3) t<sub>HZ</sub> and t<sub>LZ</sub> transitions occur in the same access time windows as valid data transitions. These parameters are not referenced to a specific voltage level, but specify when the device output is no longer driving (HZ), or begins driving (LZ).
- 4) The specific requirement is that DQS be valid (High, Low, or at some point on a valid transition) on or before this CK edge. A valid transition is defined as monotonic, and meeting the input slew rate specifications of the device. When no writes were previously in progress on the bus, DQS will be transitioning from High-Z to logic LOW. If a previous write was in progress, DQS could be HIGH, LOW, or transitioning from HIGH to LOW at this time, depending on tDQSS.
- 5) The maximum limit for this parameter is not a device limit. The device will operate with a greater value for this parameter, but system performance (bus turnaround) will degrade accordingly.
- 6) For command/address slew rate  $\geq 0.5$ V/ns and <1.0V/ns. For CK &  $\overline{\text{CK}}$  slew rate  $\geq 1.0$ V/ns.
- 7) A maximum of eight AUTO REFRESH commands can be posted to any given DDR SDRAM device.
- 8) Power-up sequence is described in Note 10
- 9) A.C. Test Conditions

#### Table 18. SSTL 2 Interface

Reference Level of Output Signals (VREF)	0.5 x VDDQ
Output Load Reference to the Test Load	
Input Signal Levels	V <sub>REF</sub> + 0.31 V / V <sub>REF</sub> - 0.31 V
Input Signals Slew Rate	1 V/ns
Reference Level of Input Signals	0.5 x VDDQ

Figure 3. SSTL 2 A.C. Test Load



Confidential - 14 of 64 - Rev.1.0 Aug. 2020



#### 10) Power up Sequence

Power up must be performed in the following sequence.

- 1. Apply power to  $V_{DD}$  before or at the same time as  $V_{DDQ}$ ,  $V_{TT}$  and  $V_{REF}$  when all input signals are held "NOP" state and maintain CKE "LOW".
- 2. Start clock and maintain stable condition for minimum  $200\mu s$ .
- 3. Issue a "NOP" command and keep CKE "HIGH"
- 4. Issue a "Precharge All" command.
- 5. Issue EMRS enable DLL.
- 6. Issue MRS reset DLL. (An additional 200 clock cycles are required to lock the DLL).
- 7. Precharge all banks of the device.
- 8. Issue two or more Auto Refresh commands.
- 9. Issue MRS with A8 to low to initialize the mode register.

Confidential - 15 of 64 - Rev.1.0 Aug. 2020

#### 11) Overshoot/Undershoot Specification

Table 19. AC Overshoot/Undershoot Specification

Parameter	Values	Unit
Maximum peak amplitude allowed for overshoot	1.5	V
Maximum peak amplitude allowed for undershoot	1.5	V
The area between the overshoot signal and VDD must be less than or equal to	4.5	V-ns
The area between the undershoot signal and GND must be less than or equal to	4.5	V-ns

Figure 4. Address and Control AC Overshoot and Undershoot Definition





Table 20. AC Overshoot/Undershoot Specification

Parameter	Values	Unit
Maximum peak amplitude allowed for overshoot	1.2	V
Maximum peak amplitude allowed for undershoot	1.2	V
The area between the overshoot signal and VDD must be less than or equal to	2.4	V-ns
The area between the undershoot signal and GND must be less than or equal to	2.4	V-ns

Figure 5. DQ/DM/DQS AC Overshoot and Undershoot Definition




Confidential - 16 of 64 - Rev.1.0 Aug. 2020



### **Timing Waveforms**

Figure 6. Activating a Specific Row in a Specific Bank



Confidential - 17 of 64 - Rev.1.0 Aug. 2020

Figure 7. tRCD and tRRD Definition






Figure 8. READ Command



CA=Column Address
BA=Bank Address
EN AP=Enable Autoprecharge
DIS AP=Disable Autoprecharge



Figure 9. Read Burst Required CAS Latencies (CL=2)




DO n=Data Out from column n

**Burst Length=4** 

3 subsequent elements of Data Out appear in the programmed order following DO n

Don't Care


Figure 10. Read Burst Required CAS Latencies (CL=2.5)



Don't Care



Figure 11. Read Burst Required CAS Latencies (CL=3)



DO n=Data Out from column n

**Burst Length=4** 


3 subsequent elements of Data Out appear in the programmed order following DO n



Confidential - 20 of 64 - Rev.1.0 Aug. 2020



Figure 12. Consecutive Read Bursts Required CAS Latencies (CL=2)



DO n (or o)=Data Out from column n (or column o)

Burst Length=4 or 8 (if 4, the bursts are concatenated; if 8, the second burst interrupts the first)

3 subsequent elements of Data Out appear in the programmed order following DO n

 $3\ (or\ 7)$  subsequent elements of Data Out appear in the programmed order following DO o


Read commands shown must be to the same device



Confidential - 21 of 64 - Rev.1.0 Aug. 2020



Figure 13. Consecutive Read Bursts Required CAS Latencies (CL=2.5)



DO n (or o)=Data Out from column n (or column o)

Burst Length=4 or 8 (if 4, the bursts are concatenated; if 8, the second burst interrupts the first)

3 subsequent elements of Data Out appear in the programmed order following DO n

3 (or 7) subsequent elements of Data Out appear in the programmed order following DO o


Read commands shown must be to the same device



Confidential - 22 of 64 - Rev.1.0 Aug. 2020



Figure 14. Consecutive Read Bursts Required CAS Latencies (CL=3)



DO n (or o)=Data Out from column n (or column o)

Burst Length=4 or 8 (if 4, the bursts are concatenated; if 8, the second burst interrupts the first)

3 subsequent elements of Data Out appear in the programmed order following DO n


3 (or 7) subsequent elements of Data Out appear in the programmed order following DO o Read commands shown must be to the same device



Confidential - 23 of 64 - Rev.1.0 Aug. 2020



Figure 15. Non-Consecutive Read Bursts Required CAS Latencies (CL=2)




DO n (or o)=Data Out from column n (or column o)

**Burst Length=4** 

3 subsequent elements of Data Out appear in the programmed order following DO n (and following DO o)

Don't Care

Figure 16. Non-Consecutive Read Bursts Required CAS Latencies (CL=2.5)



DO n (or o)=Data Out from column n (or column o)


Burst Length=4

3 subsequent elements of Data Out appear in the programmed order following DO n (and following DO o)

Don't Care



Figure 17. Non-Consecutive Read Bursts Required CAS Latencies (CL=3)




**Burst Length=4** 

3 subsequent elements of Data Out appear in the programmed order following DO n (and following DO o)

Don't Care

Confidential - 25 of 64 - Rev.1.0 Aug. 2020

Figure 18. Random Read Accesses Required CAS Latencies (CL=2)




DO n, etc. =Data Out from column n, etc.

n', etc. =the next Data Out following DO n, etc. according to the programmed burst order Burst Length=2,4 or 8 in cases shown. If burst of 4 or 8, the burst is interrupted Reads are to active rows in any banks

Don't Care

Figure 19. Random Read Accesses Required CAS Latencies (CL=2.5)




DO n, etc. =Data Out from column n, etc.

n', etc. =the next Data Out following DO n, etc. according to the programmed burst order Burst Length=2,4 or 8 in cases shown. If burst of 4 or 8, the burst is interrupted Reads are to active rows in any banks

Don't Care



Figure 20. Random Read Accesses Required CAS Latencies (CL=3)




DO n, etc. =Data Out from column n, etc.

n', etc. =the next Data Out following DO n, etc. according to the programmed burst order Burst Length=2,4 or 8 in cases shown. If burst of 4 or 8, the burst is interrupted Reads are to active rows in any banks



Confidential - 27 of 64 - Rev.1.0 Aug. 2020

Figure 21. Terminating a Read Burst Required CAS Latencies (CL=2)




DO n = Data Out from column n

Cases shown are bursts of 8 terminated after 4 data elements

3 subsequent elements of Data Out appear in the programmed order following DO n

Don't Care

Figure 22. Terminating a Read Burst Required CAS Latencies (CL=2.5)




Cases shown are bursts of 8 terminated after 4 data elements

3 subsequent elements of Data Out appear in the programmed order following DO n

Don't Care



Figure 23. Terminating a Read Burst Required CAS Latencies (CL=3)



DO n = Data Out from column n

Cases shown are bursts of 8 terminated after 4 data elements


3 subsequent elements of Data Out appear in the programmed order following DO n



Confidential - 29 of 64 - Rev.1.0 Aug. 2020



Figure 24. Read to Write Required CAS Latencies (CL=2)



DO n (or o)= Data Out from column n (or column o)

Burst Length= 4 in the cases shown (applies for bursts of 8 as well; if burst length is 2, the BST command shown can be NOP)


1 subsequent element of Data Out appears in the programmed order following DO n Data in elements are applied following DI o in the programmed order



Confidential - 30 of 64 - Rev.1.0 Aug. 2020



Figure 25. Read to Write Required CAS Latencies (CL=2.5)



DO n (or o)= Data Out from column n (or column o)

Burst Length= 4 in the cases shown (applies for bursts of 8 as well; if burst length is 2, the BST command shown can be NOP)


1 subsequent element of Data Out appears in the programmed order following DO n Data in elements are applied following DI o in the programmed order

Don't Care

Confidential - 31 of 64 - Rev.1.0 Aug. 2020



Figure 26. Read to Write Required CAS Latencies (CL=3)



DO n (or o)= Data Out from column n (or column o)

Burst Length= 4 in the cases shown (applies for bursts of 8 as well; if burst length is 2, the BST command shown can be NOP)


1 subsequent element of Data Out appears in the programmed order following DO n Data in elements are applied following DI o in the programmed order



Confidential - 32 of 64 - Rev.1.0 Aug. 2020



Figure 27. Read to Precharge Required CAS Latencies (CL=2)



DO n = Data Out from column n

Cases shown are either uninterrupted bursts of 4, or interrupted bursts of 8 3 subsequent elements of Data Out appear in the programmed order following DO n

Precharge may be applied at (BL/2) tCK after the READ command

Note that Precharge may not be issued before tRAS ns after the ACTIVE command for applicable banks


The Active command may be applied if tRC has been met



Confidential - 33 of 64 - Rev.1.0 Aug. 2020



Figure 28. Read to Precharge Required CAS Latencies (CL=2.5)



DO n = Data Out from column n

Cases shown are either uninterrupted bursts of 4, or interrupted bursts of 8

3 subsequent elements of Data Out appear in the programmed order following DO n

Precharge may be applied at (BL/2) tCK after the READ command

Note that Precharge may not be issued before tRAS ns after the ACTIVE command for applicable banks


The Active command may be applied if tRC has been met



Confidential - 34 of 64 - Rev.1.0 Aug. 2020



Figure 29. Read to Precharge Required CAS Latencies (CL=3)



DO n = Data Out from column n

Cases shown are either uninterrupted bursts of 4, or interrupted bursts of 8

3 subsequent elements of Data Out appear in the programmed order

3 subsequent elements of Data Out appear in the programmed order following DO n

Precharge may be applied at (BL/2) tCK after the READ command

Note that Precharge may not be issued before tRAS ns after the ACTIVE command for applicable banks


The Active command may be applied if tRC has been met



Confidential - 35 of 64 - Rev.1.0 Aug. 2020



Figure 30. Write Command




CA=Column Address BA=Bank Address EN AP=Enable Autoprecharge DIS AP=Disable Autoprecharge



Confidential - 36 of 64 - Rev.1.0 Aug. 2020



Figure 31. Write Max DQSS



DI n = Data In for column n

3 subsequent elements of Data In are applied in the programmed order following DI n

A non-interrupted burst of 4 is shown


A10 is LOW with the WRITE command (AUTO PRECHARGE disabled)



Confidential - 37 of 64 - Rev.1.0 Aug. 2020



Figure 32. Write Min DQSS



DI n = Data In for column n

3 subsequent elements of Data In are applied in the programmed order following DI n


A non-interrupted burst of 4 is shown

A10 is LOW with the WRITE command (AUTO PRECHARGE disabled)



Confidential - 38 of 64 - Rev.1.0 Aug. 2020

Figure 33. Write Burst Nom, Min, and Max tDQSS



DI n = Data In for column n

3 subsequent elements of Data are applied in the programmed order following DI n A non-interrupted burst of 4 is shown


A10 is LOW with the WRITE command (AUTO PRECHARGE disabled) DM=UDM & LDM  $\,$ 

Don't Care

Confidential - 39 of 64 - Rev.1.0 Aug. 2020



Figure 34. Write to Write Max tDQSS



DI n, etc. = Data In for column n,etc.

3 subsequent elements of Data In are applied in the programmed order following DI n


3 subsequent elements of Data In are applied in the programmed order following DI o

Non-interrupted bursts of 4 are shown

DM= UDM & LDM



Figure 35. Write to Write Max tDQSS, Non Consecutive



DI n, etc. = Data In for column n, etc.

3 subsequent elements of Data In are applied in the programmed order following DI n


3 subsequent elements of Data In are applied in the programmed order following DI o

Non-interrupted bursts of 4 are shown

DM= UDM & LDM



Figure 36. Random Write Cycles Max tDQSS



DI n, etc. = Data In for column n, etc.

n', etc. = the next Data In following DI n, etc. according to the programmed burst order Programmed Burst Length 2, 4, or 8 in cases shown

If burst of 4 or 8, the burst would be truncated


Each WRITE command may be to any bank and may be to the same or different devices DM= UDM & LDM



Confidential - 42 of 64 - Rev.1.0 Aug. 2020



Figure 37. Write to Read Max tDQSS Non Interrupting



DI n, etc. = Data In for column n, etc.

 $1\ subsequent\ elements\ of\ Data\ \ In\ are\ applied\ in\ the\ programmed\ order\ following\ DI\ n$ 

A non-interrupted burst of 2 is shown


tWTR is referenced from the first positive CK edge after the last Data In Pair

A10 is LOW with the WRITE command (AUTO PRECHARGE is disabled)

The READ and WRITE commands are to the same devices but not necessarily to the same bank DM= UDM & LDM



Figure 38. Write to Read Max tDQSS Interrupting



DI n, etc. = Data In for column n, etc.

1 subsequent elements of Data In are applied in the programmed order following DI n

An interrupted burst of 8 is shown, 2 data elements are written

tWTR is referenced from the first positive CK edge after the last Data In Pair

A10 is LOW with the WRITE command (AUTO PRECHARGE is disabled)


The READ and WRITE commands are to the same devices but not necessarily to the same bank DM= UDM & LDM



Confidential - 44 of 64 - Rev.1.0 Aug. 2020



Figure 39. Write to Read Max tDQSS, ODD Number of Data, Interrupting



DI n = Data In for column n

An interrupted burst of 8 is shown, 1 data elements are written

tWTR is referenced from the first positive CK edge after the last Data In Pair (not the last desired Data In element)

A10 is LOW with the WRITE command (AUTO PRECHARGE is disabled)


The READ and WRITE commands are to the same devices but not necessarily to the same bank DM= LDM & UDM

Don't Care

Confidential - 45 of 64 - Rev.1.0 Aug. 2020



Figure 40. Write to Precharge Max tDQSS, NON-Interrupting



DI n = Data In for column n

 $\bf 1$  subsequent elements of Data  $\,$  In are applied in the programmed order following DI n A non-interrupted burst of 2 is shown


tWR is referenced from the first positive CK edge after the last Data In Pair A10 is LOW with the WRITE command (AUTO PRECHARGE is disabled) DM= UDM & LDM



Confidential - 46 of 64 - Rev.1.0 Aug. 2020



Figure 41. Write to Precharge Max tDQSS, Interrupting



DI n = Data In for column n

An interrupted burst of 4 or 8 is shown, 2 data elements are written tWR is referenced from the first positive CK edge after the last Data In Pair A10 is LOW with the WRITE command (AUTO PRECHARGE is disabled)

\*1 = can be don't care for programmed burst length of 4


\*2 = for programmed burst length of 4, DQS becomes don't care at this point DM= UDM & LDM

Don't Care

Confidential - 47 of 64 - Rev.1.0 Aug. 2020



Figure 42. Write to Precharge Max tDQSS ODD Number of Data Interrupting



DI n = Data In for column n

An interrupted burst of 4 or 8 is shown, 1 data element is written tWR is referenced from the first positive CK edge after the last Data In Pair A10 is LOW with the WRITE command (AUTO PRECHARGE is disabled)

\*1 = can be don't care for programmed burst length of 4


\*2 = for programmed burst length of 4, DQS becomes don't care at this point DM= UDM & LDM



Confidential - 48 of 64 - Rev.1.0 Aug. 2020




Figure 43. Precharge Command



Don't Care


Confidential - 49 of 64 - Rev.1.0 Aug. 2020

Figure 44. Power-Down




Don't Care

Figure 45. Clock Frequency Change in Precharge



Confidential - 50 of 64 - Rev.1.0 Aug. 2020

Figure 46. Data input (Write) Timing




DI n = Data In for column n

**Burst Length = 4 in the case shown** 

3 subsequent elements of Data In are applied in the programmed order following DI n

Don't Care

Figure 47. Data Output (Read) Timing




**Burst Length = 4 in the case shown** 

Confidential - 51 of 64 - Rev.1.0 Aug. 2020



#### Figure 48. Initialize and Mode Register Sets




<sup>\*=</sup>VTT is not applied directly to the device, however tVTD must be greater than or equal to zero to avoid device latch-up.

\*\*= tMRD is required before any command can be applied, and 200 cycles of CK are required before any executable command can be applied the two auto Refresh commands may be moved to follow the first MRS but precede the second PRECHARGE ALL command.

Don't Care

Confidential - 52 of 64 - Rev.1.0 Aug. 2020

Figure 49. Power Down Mode




No column accesses are allowed to be in progress at the time Power-Down is entered \*=If this command is a PRECHARGE ALL (or if the device is already in the idle state) then the Power-Down mode shown is Precharge Power Down. If this command is an ACTIVE (or if at least one row is already active) then the Power-Down mode shown is active Power Down.

Don't Care

Confidential - 53 of 64 - Rev.1.0 Aug. 2020



Figure 50. Auto Refresh Mode




\*= "Don't Care", if A10 is HIGH at this point; A10 must be HIGH if more than one bank is active (i.e., must precharge all active banks)
PRE = PRECHARGE, ACT = ACTIVE, RA = Row Address, BA = Bank Address, AR = AUTOREFRESH
NOP commands are shown for ease of illustration; other valid commands may be possible after tRFC
DM, DQ and DQS signals are all "Don't Care" /High-Z for operations shown

Don't Care

Confidential - 54 of 64 - Rev.1.0 Aug. 2020



Figure 51. Self Refresh Mode




<sup>\* =</sup> Device must be in the "All banks idle" state prior to entering Self Refresh mode

<sup>\*\*</sup> = tXSNR is required before any non-READ command can be applied, and tXSRD (200 cycles of CK) is required before a READ command can be applied.



Confidential - 55 of 64 - Rev.1.0 Aug. 2020

Figure 52. Read without Auto Precharge



DO n = Data Out from column n

Burst Length = 4 in the case shown

3 subsequent elements of Data Out are provided in the programmed order following DO n

DIS AP = Disable Autoprecharge

\* = "Don't Care", if A10 is HIGH at this point


PRE = PRECHARGE, ACT = ACTIVE, RA = Row Address, BA = Bank Address, AR = AUTOREFRESH

NOP commands are shown for ease of illustration; other commands may be valid at these times

Precharge may not be issued before tRAS ns after the ACTIVE command for applicable banks



Figure 53. Read with Auto Precharge



DO n = Data Out from column n

Burst Length = 4 in the case shown

3 subsequent elements of Data Out are provided in the programmed order following DO n

EN AP = Enable Autoprecharge

ACT = ACTIVE, RA = Row Address


NOP commands are shown for ease of illustration; other commands may be valid at these times

The READ command may not be issued until tRAP has been satisfied. If Fast Autoprecharge is supported, tRAP = tRCD, else the READ may not be issued prior to tRASmin - (BL\*tCK/2)

Don't Care

Confidential - 57 of 64 - Rev.1.0 Aug. 2020

Figure 54. Bank Read Access



3 subsequent elements of Data Out are provided in the programmed order following DO n

DIS AP = Disable Autoprecharge


\* = " Don't Care", if A10 is HIGH at this point

 $PRE = PRECHARGE, ACT = ACTIVE, RA = Row\ Address, BA = Bank\ Address$ 

NOP commands are shown for ease of illustration; other commands may be valid at these times

Note that  $tRCD > tRCD \ MIN$  so that the same timing applies if Autoprecharge is enabled (in which case tRAS would be limiting)

Figure 55. Write without Auto Precharge



 $\boldsymbol{3}$  subsequent elements of Data In are provided in the programmed order following DI  $\boldsymbol{n}$ 

DIS AP = Disable Autoprecharge

\*=" Don't Care", if A10 is HIGH at this point


PRE = PRECHARGE, ACT = ACTIVE, RA = Row Address, BA = Bank Address, AR = AUTOREFRESH

NOP commands are shown for ease of illustration; other commands may be valid at these times

Although tDQSS is drawn only for the first DQS rising edge, each rising edge of DQS must fall within the  $\pm$  25% window of the corresponding positive clock edge

Precharge may not be issued before tRAS ns after the ACTIVE command for applicable banks

Figure 56. Write with Auto Precharge



DI n = Data In from column n

Burst Length = 4 in the case shown

3 subsequent elements of Data Out are provided in the programmed order following DI  $\boldsymbol{n}$ 

EN AP = Enable Autoprecharge


ACT = ACTIVE, RA = Row Address, BA = Bank Address

NOP commands are shown for ease of illustration; other commands may be valid at these times

Although tDQSS is drawn only for the first DQS rising edge, each rising edge of DQS must fall within the ± 25%

window of the corresponding positive clock edge

Figure 57. Bank Write Access



DI n = Data In from column n

Burst Length = 4 in the case shown

3 subsequent elements of Data Out are provided in the programmed order following DI n

DIS AP = Disable Autoprecharge

\*=" Don't Care", if A10 is HIGH at this point

PRE = PRECHARGE, ACT = ACTIVE, RA = Row Address, BA = Bank Address


NOP commands are shown for ease of illustration; other commands may be valid at these times

Although tDQSS is drawn only for the first DQS rising edge, each rising edge of DQS must fall within the  $\pm\,25\%$  window of the corresponding positive clock edge

 $\label{lem:command} Precharge\ may\ not\ be\ issued\ before\ tRAS\ ns\ after\ the\ ACTIVE\ command\ for\ applicable\ banks$ 



Figure 58. Write DM Operation



DI n = Data In from column n

Burst Length = 4 in the case shown

 $3\ subsequent\ elements\ of\ Data\ In\ are\ provided\ in\ the\ programmed\ order\ following\ DI\ n$ 

DIS AP = Disable Autoprecharge

\*=" Don't Care", if A10 is HIGH at this point

PRE = PRECHARGE, ACT = ACTIVE, RA = Row Address, BA = Bank Address


NOP commands are shown for ease of illustration; other commands may be valid at these times

Although tDQSS is drawn only for the first DQS rising edge, each rising edge of DQS must fall within the  $\pm~25\%$  window of the corresponding positive clock edge

Precharge may not be issued before tRAS ns after the ACTIVE command for applicable banks



Figure 59. 60ball FBGA Package 8x13x1.2 mm(max) Outline Drawing Information



Symbol	Dimension (inch)			Dimension (mm)		
	Min	Nom	Max	Min	Nom	Max
Α	1	1	0.047	1	1	1.20
A1	0.012	0.014	0.016	0.30	0.35	0.40
D	0.311	0.315	0.319	7.90	8.00	8.10
E	0.508	0.512	0.516	12.90	13.00	13.10
D1		0.252			6.40	
E1	I	0.433	1	I	11.00	1
e1	I	0.039	1	I	1.00	1
e2	I	0.031	1	I	0.80	1
b	0.016	0.018	0.020	0.40	0.45	0.50
F		0.126			3.20	

Confidential - 63 of 64 - Rev.1.0 Aug. 2020



#### PART NUMBERING SYSTEM

AS4C	16M16D1	-5	В	А	N	XX
DRAM	16M16 =16M x 16 D1=DDR1	5=200MHz	B=FBGA	A=Automotive temp -40°C~ 105°C	Indicates Pb and Halogen Free	Packing Type None:Tray TR:Reel



Alliance Memory, Inc. 12815 NE 124th Street Suite D Kirkland, WA 98034

Tel: 425-898-4456 Fax: 425-896-8628 www.alliancememory.com Copyright © Alliance Memory All Rights Reserved

© Copyright 2007 Alliance Memory, Inc. All rights reserved. Our three-point logo, our name and Intelliwatt are trademarks or registered trademarks of Alliance. All other brand and product names may be the trademarks of their respective companies. Alliance reserves the right to make changes to this document and its products at any time without notice. Alliance assumes no responsibility for any errors that may appear in this document. The data contained herein represents Alliance's best data and/or estimates at the time of issuance. Alliance reserves the right to change or correct this data at any time, without notice. If the product described herein is under development, significant changes to these specifications are possible. The information in this product data sheet is intended to be general descriptive information for potential customers and users, and is not intended to operate as, or provide, any guarantee or warrantee to any user or customer. Alliance does not assume any responsibility or liability arising out of the application or use of any product described herein, and disclaims any express or implied warranties related to the sale and/or use of Alliance products including liability or warranties related to fitness for a particular purpose, merchantability, or infringement of any intellectual property rights, except as express agreed to in Alliance's Terms and Conditions of Sale (which are available from Alliance). All sales of Alliance products are made exclusively according to Alliance's Terms and Conditions of Sale. The purchase of products from Alliance does not convey a license under any patent rights, copyrights; mask works rights, trademarks, or any other intellectual property rights of Alliance or third parties. Alliance does not authorize its products for use as critical components in life-supporting systems where a malfunction or failure may reasonably be expected to result in significant injury to the user, and the inclusion of Alliance products in such life-supporting systems implies that the manufacturer assumes all risk of such use and agrees to indemnify Alliance against all claims arising from such use.

Confidential - 64 of 64 - Rev.1.0 Aug. 2020